



TIEFFE[®]
CHEMICAL SOLVING

FAP CLEANER

FAP/DPF
filter cleaner



*Your filter as new,
WITHOUT REPLACEMENT!*

www.tf-pulire.it



FAP CLEANER



TIMING

120 /
240 MIN.



CLEANING

99%




COST

€ €€€€€

CLEANING PROCESS

1

DISASSEMBLE THE FILTER FROM THE VEHICLE



2

FILTER IMMERSION



Vertically immerse the filter inside a tank (tall and narrow) and fill it up with FAP CLEANER.

The level of liquid should be 10 cm more than the FAP/DPF filter. Leave it immersed for min. 50 minutes (for partially clogged filters) up to a few hours (for completely clogged filters).

3

LIQUID EXTRACTION AND FILTER DRAINING



Remove the filter from the tank. Let the filter drain over the tank and collect the drained liquid.

FAP CLEANER after a standard use can be recovered and re-used for the cleaning of EGR valves.

4

RINSING PHASE WITH HIGH PRESSURE WATER




Rinse thoroughly at low pressure.

Finalize with high pressure rinsing.

(The product contains a foam marker to indicate that rinsing is complete when foam is no longer present).

**BEFORE
CLEANING**



**AFTER
CLEANING**