



**T I E F F E**  
CHEMICAL SOLVING

## **FORNOLUXPLUS**

### **LIQUID DEGREASER DETERGENT FOR OVENS AND GRILLS**

FORNOLUX is a liquid detergent formulated to manually remove cooking residuals of sauces, oils, etc. from ovens or grills. It has an effective cleaning and descaling action.

#### **CHARACTERISTICS**

- clear, slightly viscose liquid
  - NON flammable
  - easy to rinse
  - completely biodegradable
  - caustic
- Suitable to clean **OVENS, GRILLS, HOT PLATES** ecc.

It removes dirt and eliminates bad odours.

#### DIRECTIONS FOR USE

**Use FORNOLUX pure, as received** in its container, by applying on the parts to be cleaned (better if still warm) with a sponge, cloth, or by spraying it on the parts.

**Let it work for 5 to 10 minutes**, or longer for stubborn dirt.

Wipe with a cloth or a sponge and **rinse abundantly**.

**IT MUST NOT be used on aluminum.**

#### **PRECAUTIONS**

Refer to the safety data sheet.