

## **OVEN SENSITIVE TAB**

## DETERGENT TABS FOR SELF-CLEANING OVENS BASED ON POTASSIUM SALTS

It is an innovative formulation based on potassium salts with high aggressiveness on dirt and maximum respect over time of the oven components, designed for the cleaning phase inside the cooking chambers of professional self-cleaning kitchen ovens.

The Oven Sensitive Tabs perform a strong decarbonising action on cooking residues and also remove residual odors.

## INSTRUCTION FOR USE

- Position the tab in the appropriate housing indicated by the oven manufacturer. If a housing is not provided, put the pad on the chamber grid before starting the solubilization cycle provided by the manufacturer.
- Enter a number of tabs according to the washing instructions of the oven manufacturer
- The tab must be appropriately solubilized so that it can perform its degreasing and decarbonising action on the treated parts. Therefore, a water temperature of at least 85 ° C is recommended to complete its melting phase.
- At the end of the washing phase, always start rinsing cycles
- Always handle the pad with protective gloves

## **PRECAUTIONS**

Consult the safety data sheet.

Emissione: MC 03/17 Rev: IP 04/20